

## 2015 JEEP RENEGADE REAR SOLID BENCH REMOVAL INSTRUCTIONS

Dear Customer;

Thank you for purchasing what is known to be the best automobile seat covers in the industry! As we are unable to assist you in installing your Wet Okole Hawaii waterproof sport seat covers, we offer these special instructions. Most vehicle installations are self explanatory. In the case of any problems or concerns please feel free to call for technical support at our toll-free number (888)246-5653. Enjoy your Wet Okole Hawaii Seat covers and thank you for your business!

This instruction guide teaches you how to remove the seat bottom (the part you sit on) from the rear solid 60/40 bench so that you can install your Wet Okole Hawaii seat covers properly. Please follow the steps as instructed below to securely remove the seat bottom.

### STEP 1



To release both the 60% and 40% backrests from their stationary position simply press the release handle on each side of the backrest before pushing them forward.

### STEP 2



From inside the trunk push the 60% and 40% backrests (the parts you lean against) forward, away from their stationary position.

### STEP 3



**Important**  
From inside the trunk lift the carpet which is laying over the back side of the backrests and underneath you will find two torx bolts which are securing the seat bottom in place.

### STEP 4



**Important**  
Be sure to remove these bolts before attempting step 5. To remove the bolts use a torx bit size T-40 with an extension and ratchet.

### STEP 5



In this final step some force is **necessary** to remove the seat bottom from its stationary position which is held in place by two forward alignment inserts as illustrated in the next step. These alignment inserts simply snap on and off. There is no releaser.

### STEP 6



Step into your vehicle and grab the seat bottom from underneath the front edge and pull up until the seat bottom snaps out of place. Once the forward alignment inserts are revealed you can securely remove the seat bottom.